

# H600 AIR PURIFIER USER MANUAL

· Airp

## CONTENTS

IMPORTANT SAFEGUARDS	4
THE AIRPURA SYSTEM	5
GETTING CLEAN AIR AT HOME	6
HOW TO CHANGE YOUR FILTER	8
TECHNICAL SPECS	13
WARRANTY	14



Congratulations on your purchase of the Airpura air purifier. Please read this user manual carefully before operating to familiarize yourself with the unit and the proper usage of it. Keep this user manual in a safe place for future reference.

## IMPORTANT SAFEGUARDS

- Inspect the exterior of your Airpura to verify that there is no damage from shipping.
- If any damage is noted, please follow the instructions from the distributor returns policy.
- Wipe the unit with a damp cloth to remove any dust from packaging.
- Please ensure air purifier is turned OFF when plugging into a power source. Failure to do so may result in motor potentially stalling and/or burning.
- Plug the unit into a regular grounded 110-volt outlet.
- Cleaning and user maintenance should not be made by children without supervision.
- Appliances that are obviously damaged must not be operated.

# THE AIRPURA SYSTEM

EXPERIENCE THE EVOLUTION OF CLEAN AIR WITH THE AIRPURA SYSTEM



## GUIDE TO GETTING CLEAN AIR AT HOME

You have taken the first step in creating a healthy environment. It should be noted that this purifier is not intended to be the main protection against pollutants. The source of your pollution should always be eliminated or reduced. The purifier will sustain clean air in your space. This air purifier is not intended for industrial use.

#### **GETTING STARTED**

When you receive your unit, turn on the unit to the MAX level and allow it to run for at least 30 minutes to burn off any residuals from transport and allow filters to settle in.

#### **REGULATING FAN SPEED**

The purifier can be set to run at variable speed settings allowing you to control your air flow.





Low setting



Purifier turned off

#### FILTER REPLACEMENT DATE STICKER

<b>H600</b> Filter Replacement Date
Prefilter:
HEPA:
HI-C Carbon Weave:

**IMPORTANT:** In order to keep your purifier in peak condition, it is essential to replace your filters regularly. To help remind you, a **Filter Replacement Date sticker** has been included with the purchase of this unit. Fill it out with the dates you need to replace your filters using the recommendations provided on page 8 of this manual. Affix to your purifier as a reminder.

#### TIPS TO OBTAIN THE BEST RESULTS

- It is recommended to run your purifier at low speeds, 24 hours a day, 7 days a week. Running it at a low speed allows for maximum dwell time of chemicals and VOCs in the air through both the carbon and HEPA filters thus delivering superior filtration.
- Purifier should be positioned at least 1 foot away from any wall or furniture to prevent obstruction of air intake.
- Purifier should be put in the general area that has the most pollution or the room you spend the most time in. For example, if you spend most of your day in the office or living room, keep it there. At night, you can move it to your bedroom area.
- Always maintain a humidity level of 35% or less in your home to ensure the unit is operating at optimal levels. Overly humid conditions can have an adverse effect on the performance of the carbon. When using purifier with a dehumidifier, please keep dehumidifier at least 6 feet away.
- At the beginning of product use, it is possible the carbon filter may emit an odor. This smell will dissipate after 2 weeks.
- It is not recommended to operate purifier in area where food is being cooked, particularly near fish, meats and fried foods. Oil on carbon filter can shorten filter life. Proper ventilation should be used when cooking. After area has been properly vented, the purifier can be used to maintain fresh air.

## CHANGING YOUR FILTERS

Filter should be changed regularly as per recommended time indicated. These recommendations are based on normal usage and pollution levels. Higher than average levels of pollution may cause the filters to saturate quicker and may require a filter change in less than recommended times.

#### SUGGESTED REPLACEMENT TIMES

	Filter	Recommended replacement time
1. Prefilter*	<b>Poly Prefilter 600</b> (2-pack)	<b>6 months</b> under normal conditions <b>3 months</b> for high pollution levels
2. Particle filter	HEPA 600RVHU Filter (99.97 % efficient @ 0.3 Microns)	<b>5 years</b> under normal conditions <b>3 years</b> for high pollution levels
3. Chemical gas & odor filter	HI-C Carbon Weave	<b>4-6 months</b> under normal conditions <b>2-3 months</b> for high pollution levels

#### **\*PREFILTER HANDY TIP!**

The prefilter can be vacuumed from the exterior of the unit once a month or more often.

#### To vacuum the Prefilter

Use the brush attachment on your vacuum cleaner and vacuum slowly around the exterior metal surface of the filter chamber.

There are 3 sets of filters in your Airpura H600.



**SAFETY NOTE:** Power must always be disconnected when replacing your filters.

Before attempting to replace your filters, follow steps to open the filter chamber:

#### **OPENING THE FILTER CHAMBER**







- 1. Turn the air purifier over and remove 4 retaining screws using a screwdriver.
- 2. Remove cover.
- 3. Remove gasket and set aside.

#### **REPLACING THE HEPA**



1. Remove the HEPA filter located in the center of the unit.



 Replace with the new HEPA filter\*.
 \*Ensure the open side of the HEPA filter is placed headfirst.


#### **REPLACING THE HI-C CARBON WEAVE**



1. Remove the HEPA filter located in the center of the unit and set aside.



2. Remove the HI-C carbon weave.



3. Unroll the HI-C carbon weave from the metal frame and discard.

#### **REPLACING THE PREFILTER**



1. Remove the HEPA filter located in the center of the unit and set aside.



A 2. Remove the HI-C carbon weave.



3. Remove the old prefilter.



4. Roll new prefilter around the sides of the purifier.



5. Insert the HI-C 6. Repla carbon back into the filter chamber. set aside





4. Take your new HI-C carbon.



5. Wrap around the metal frame.



6. Insert the HI-C carbon back into the filter chamber.



7. Replace the HEPA filter that had been set aside back into the center of the filter chamber.





1. Replace the gasket on top of filters.



2. Replace the

cover, ensuring the indentation in the cover,

lines up with the center of the HEPA filter.

3. Using a screwdriver, replace the 4 screws and tighten.

4. Carefully turn the air purifier back onto casters.



11

### Filter Replacement "Mix and Match"

Airpura offers you the opportunity to change the configuration of some of your filters should your air filtration needs change in the future.

	Prefilter	HEPA: Particle filtration	Carbon: Chemical gas & odors
Upgrade		<ul> <li>HEPA 14 Filter (99.99% of airborne particles ≥ 0.3 microns)</li> <li>ULPA Filter (99.9999% of airborne particles ≥ 0.1 microns)</li> </ul>	<ul> <li>-18 lbs impregnated carbon filter: 17% potassium iodide carbon, 83% coconut shell carbon</li> <li>The potassium iodide increases the adsorption of the carbon allowing for enhanced filtration</li> <li>-18 lbs impregnated carbon filter: 17% potassium permanganate carbon, 83% coconut shell carbon</li> <li>The potassium permanganate is a powerful oxidizer that accelerates the binding of VOCs such as formaldehyde</li> <li>-18 lbs German Carbon Filter</li> <li>A premium filter designed for individuals sensitive to odors</li> <li>-18 lbs Coconut carbon filter</li> <li>A robust carbon filter designed to eliminate everyday odors and chemicals</li> </ul>
Alternative	<ul> <li>Tar Barrier Good for reducing tars contained in tobacco smoke</li> <li>Cotton Prefilter</li> </ul>		

## TECHNICAL SPECS

**Particle removal** Over 40 ft<sup>2</sup> true HEPA (Measured only 1 side) 12 pleats per inch to maximize filtration Pleats warm rolled with separators

**Odor and chemical suppression** 508 in<sup>2</sup> HI-C carbon weave

**Air Flow 560 cfm** More cfm than any other home unit available

**Prefilter** 570 in<sup>2</sup> x 1 in

**Housing** Powder coat steel

**Size** 23 in x 15 in **Weight** 49 lbs total

**Watts** 120 on high / 40 on low

Sound Level 28.1 db on low (at 6 feet) 62.3 db on high (560 cfm) (Room level 25.1 db)

**Voltage options** 110V-120V or 220V-240V 50/60 Hz

ETL Certified no 113 ANSI / UL 507







## WARRANTY

#### WARRANTY FOR AIRPURA PRIVATE AND RESIDENTIAL USE

Where the Airpura Air Purifier is used for private or residential purposes, the following warranty applies. The determination of the type of use will be made exclusively by Airpura Industries Inc.

If within five (5) years from the date of the original purchase by the end user from the Authorized Dealer, an Airpura R600, C600, C600 DLX, T600, T600 DLX, H600, V600, P600, F600, F600 DLX, G600, G600 DLX or UV 600 (with the exception of filters or UV lamps) is proved to be defective by reason only of faulty workmanship or materials, Airpura Industries Inc. will either repair or replace the part or product free of charge for labor, materials and shipping only. This decision to repair or replace will be made by Airpura.

If after five (5) years and not more than ten (10) years from the date of the original purchase by the end user from the Authorized Dealer, an Airpura R600, C600, C600 DLX, T600, T600 DLX, H600, V600, P600, F600, F600 DLX, G600, G600 DLX or UV 600 (with the exception of filters or UV lamps) is proved to be defective by reason only of faulty workmanship or materials, Airpura Industries Inc. will at their option, repair or replace the part or product free of charge for labor only. Any replacement parts deemed necessary by Airpura Industries will be charged to the purchaser.

The same warranty applies to the Airpura 1600 within two (2) years of purchase for parts and labor and within 5 years for labor only. Obvious defects must be communicated to the Authorized Dealer within 10 days from the purchase date.

This warranty shall not apply to damage caused through misuse, wear and tear, neglect, unauthorized repair or to damage caused through installation, adaptation, modification or use in an improper manner or inconsistent with Airpura's operating and maintenance instructions, wear or deterioration due to environmental conditions or to damage occurred during transit.

Airpura Industries will not be liable under this warranty for any fault or damage arising from defective workmanship, if the product has been serviced, repaired or modified by any person other than Airpura Industries Inc. or the manufacturer's serial label has been removed or tampered with.

All products returned for service or repair must be accompanied with a RA (Return Authorization) number. The RA number must be clearly visible on the external packaging. The absence of an RA number will delay the service or repair process. Any shipment to Airpura Industries Inc. not accompanied with an RA number will not be accepted or will be immediately sent back to the shipper. Please contact the dealer you purchased the unit at in order to receive an RA number prior to shipment.



www.airpura.com Toll free: 1-866-505-7872 Local : 450-978-9020